

Programmable Remote Control

User Manual for USB Programmable remote control



三、 Second Step

1. Identify : identification of the remote control .
2. Code Select from database : select you need remote model model .
3. Program : download data to remote control .


Index

- 1、 Description and features**
- 2、 Remote control**
- 3、 Programmer**
- 4、 Identify**
- 5、 Code Program**
- 6、 Remote Learning**

一、 Description

1.PC programmable remote control is an update product for traditional universal remote control. Its main difference and characteristic is the IR code database source. Universal remote control contains IR code database in itself. PC programmable remote database is stored in PC or web server. So PC programmable remote has no risk to be out of date.

IR communication mode remote control needs a transceiver to connect to PC. Please see below photo.



2.Software

PC hardware request:

CPU: 800MHZ and above

RAM: 256Mbytes and above

Hard diask, 4G bytes and above

Operation system: Win 2000, Windows XP, Windows Vista, Win 7, Win 8.

3.Features

Compatible for PC with Windows (Programmer)

USB V2.0, HID device.

Windows XP/Windows vista/Win 7/Win 8

Powerful database

Database includes the remote control brand, model and its codes for TV, DTT, SAT, DVD, VCR, HIFI, Air Conditioner, etc. all over the world.

Internet shared database

Upload by users all over the world.

Powerful code management

Code search --- key code search.

Low power cost

2 *1.5V battery supply, can work for 1-2 years.

IR distance

>8m in the same room

二、 Remote control

This kind of remote looks same as universal remote control or learning remote control. It combines all functions of universal remote control and learning remote control. It can be programmed with any code of any device. Because its key code can be programmed to any number of key, we can design any kind of remote control with any key name to replace original remote.

Specification

Rated Power supply: 2 x 1.5V.

Power voltage range: 2.4V~3.3V.

Working power: <20mA.

Standby power: <3uA.

IR distance: >8m.

CE approval.


三、 Programmer

The IR code data is stored in PC. It needs a micro USB to PC programmable remote control.



四、 Identify


When first using or after programming, it can be identified by PC software and read back the content in the programmable remote control. Please see below photo. after identify, displayed in the software as above including code number, and key code info.



五、Code Program

1. Before program, it should be identify of programmable remote control.

After identify, it will display below photo.



1) Search and select code in database

2) Brand Filter, Model Filter

The search result is different according to “Search Option”.

3) Search Option

Characters ignored in search, this is for Brand filter and Model Filter.

Automatic search means the result will change according to the characters entered if “enabled”.

2) Program

After all codes are decided, press “ Program” menu button, place remote toward the programmer head to head, press “left” and “right” button simultaneously, then appear above photo. After it finishes, program succeeds.

六、 Remote Learning

Set up to one device :

1、 Press the POWER + MUTE button to about 3 seconds, LED lights, into the learning mode, in waiting to receive the TV remote control codes state.

2、 What needs to learn the key, the LED is blinking and remain on the remote control code in the receiving state.

3、 Will be learning remote is learning remote control receiver head, the distance of about 1 ~ 3cm, press the learning remote control button 1 ~ 2S, learning success indicator flashes twice, remains lit; if learning failure LED lights does not shine.

4、 Repeat steps 2, 3, learning a remote control code, until the other keys need to learn to learn to complete.

5、 SHIFT function key learning, need to press once SHIFT function key again to learn from other keys.

6、 The study is completed press POWER + MUTE button to exit learning; the absence of operation automatically after 5 seconds to exit the learning state.

Set up to more device :

- 1、 First click to learn the equipment key.
- 2、 Press the POWER + MUTE button to about 3 seconds, LED lights, into the learning mode, in waiting to receive the TV remote control codes state.
- 3、 What needs to learn the key, the LED is blinking and remain on the remote control code in the receiving state.
- 4、 Will be learning remote is learning remote control receiver head, the distance of about 1 ~ 3cm, press the learning remote control button 1 ~ 2S, learning success indicator flashes twice, remains lit; if learning failure LED lights does not shine.
- 5、 Repeat steps 2, 3, learning a remote control code, until the other keys need to learn to learn to complete.
- 6、 SHIFT function key learning, need to press once SHIFT function key again to learn from other keys.
- 7、 The study is completed press POWER + MUTE button to exit learning; the absence of operation automatically after 5 seconds to exit the learning state.

[illegible]

HAS YOU REALLY WELL IN

RCW[®]
Remote Controller World

**TV DVD
VCR SAT
DTT AUX
HIFI PC**

**programmable as many
times as you like**

**2 Years
guarantee**

keeps setting when
batteries removed

programmore not included

RCW ELECTRONIC

Unit 44, 7/F, Bright Way Tower, Number 33 Meng Kok Road, Kowloon, H.K.
Tel.: +00852-36697544 Fax: +00852-36697544
www.jollyonline.cc

**USB Programmable
Universal Remote Control**

Article:
RD-1st / RD-2nd / RD-3rd / RD-4ed,
RD-USB kit

English:

User manual
Insert the CD-ROM in the drive, and follow the installation instructions on the desktop window that will appear on the monitor. If the installation window does not appear, double click on the icon My PC, then with the right button of the mouse click on the "CD-ROM drive" and select "Open". Double click on the icon Setup and follow the instructions given on the installation window.

Deutsch:

Bediensungsanleitung
Legen Sie die CD-ROM in das Laufwerk ein und befolgen Sie die Installationsanweisungen der am Monitor erschienenen Dialogfenster. Wenn das Dialogfenster nicht erscheint, dann Doppelklick auf das Symbol Arbeitsplatz ausführen, dann mit rechter Maustaste auf den Symbol des CD-ROM Laufwerks klicken, "Öffnen" wählen und dann Doppelklick auf Setup. Danach die Bildschirmtexte folgen.

Français:

Notice d'installation
Insérer le CD-ROM dans le lecteur et suivre les instructions qui s'affichent dans la fenêtre de dialogue. Si la fenêtre d'installation n'apparaît pas, double-cliquer sur l'icône My PC, ensuite avec le bouton droit de la souris cliquer sur le fichier CD-ROM du périphérique "Open". Double-cliquer sur l'icône Setup et suivre les instructions données dans la fenêtre d'installation.

Nederlands:

Gebruiksaanwijzing
Plaats de CD-ROM in de CD-ROM speler van de PC en volg de installatie instructies op het scherm. Indien er geen venster verschijnt, dubbelklik op Mijn Computer. Klik dan met de rechtermuisknop op de CD-ROM drive en selecteer "Open". Dubbelklik op het setup icoon en volg de gegeven instructies in het installatie venster.

Italiano:

Istruzioni per l'uso
Inserire il CD-ROM nel drive, apparirà la macchina d'installazione e, quindi, seguire le istruzioni a video.
Se non appare nessuna finestra di dialogo fare doppio clic sull'icona Risorse del Computer quindi clic con il tasto destro del mouse sul nome del drive CD-ROM, selezionare Apri e infine fare doppio clic sull'icona Setup. Seguire le istruzioni a Video.

Español:

Instrucciones
Insertar el CD-ROM en el PC. Seguir las instrucciones de instalación que aparecen en pantalla.
Si no se abre la ventana, clicar en el icono disco/lector MY PC y continuación Selección de Iconos del drive CD-ROM, y elegir el activar/Setup. Seguir las instrucciones sobre la pantalla.

Magyar:

Hozzaértési útmutató
Helyezze be a CD-ROM-t a meghajtóba, követve azt jelenik meg a képernyőn. Amennyiben az ablak nem jelenik meg nyomja meg a D. meghajtót és válassza a setup ikont.

Sveige:

Ambilær manual
Lággj CD-Rom diskinn og fyllj instructionsina í dialog listirnar þú myndir. Önnur installatiónir eru til staðar sem dubbelklíkka þú á íkonin "My PC" og með höfuðmýsinum klíkka þú á CD-Rom láseinn og vilt "Open". Dubbelklíkka þú á setup ikoninn og fyllj instructionsina í installatiónirinni.

Slovenji:

Anašna lista
Avtaja bray CD-ROM vsesnan je vsesan aneštava aneštavopolja lističeviteljav, jo aneštavopolja o lističeviteljav, kje vključa osno besedilo in vključa občasni hrom poročila. CD vsesan knjižnica je voljan Anaš, bray vključa Setup je vsesan ošteva.

Czechy:

Vložte CD-ROM do jednotky
Při instalaci postupujte dle obrazovkových instrukcí a buďte ochotni na monitor. V případě, že se instalační okno neobjeví, klikněte levým tlačítkem myši na ikonu "Můj počítač", pak pravým tlačítkem myši klikněte na CD-ROM a vyberte možnost "Otevřít". Klikněte dvakrát na ikonu "Nastavení" (installwin). Další postupy podle instrukcí v instalačním manuálu.

English:

"Rd programmable remote" is an innovative remote control that can be programmed through any PC, any way you like it and allows to control up to 1-8 different devices

Deutsch:

"Rd programmable remote" ist eine innovative Fernbedienung, die Sie mit jedem PC nach Ihren Wünschen programmieren können und es Ihnen ermöglicht von bis zu 1-8 verschiedenen Geräten ermöglicht

Français:

Le "Rd programmable remote" est une télécommande innovante que vous pouvez programmer avec n'importe quel ordinateur comme vous le souhaitez et qui vous permet de contrôler jusqu'à 1-8 appareils différents.

Nederlands:

De Rd programmable remote is een innovatieve afstandsbediening die met de PC naar wens kan worden geprogrammeerd en toet tot 1-8 verschillende apparaten kan bedienen

Italiano:

"Rd programmable remote" è un telecomando innovativo che programmi con qualunque PC come vuoi e ti permette di controllare fino a 1-8 diversi apparecchi

Español:

"Rd programmable remote" es el mandos universal que programamos de programación con cualquier ordenador, te permite controlar hasta 1-8 aparatos diferentes y combinas tantos veces como quieras

Magyar:

A "rd" programálható távirányító egy innovatív PC-nél programozható távirányító, amely 1-8 különböző készülék szabványos funkcióit képes felváltani

Sveige:

"Rd programmable remote" är en innovativ fjärrkontroll som kan programmeras genom din PC. På ett kontrollerbar upp till 1-8 olika apparater

Sloveni:

"Rd" programabilni daljinski upravljalnik je inovativna funkcionalna naprava, ki omogoča nadziranje različnih naprav in funkcionalnosti preko računalnika ali drugega računalniškega sistema

Czechy:

Inovativní dálkový ovladač "Rd" programovatelný prostřednictvím počítače. Na ovládání až 1-8 různých zařízení

Made in P.R.C.

Serve : info@jollyonline.cc

jollyonline@msn.cn